

## SHOCK ABSORBER

## BEFIRST

 <p><b>48510-06531-BFS</b> SHOCK ABS (FR,RH)+1</p>	 <p><b>48520-06531-BFS</b> SHOCK ABS (FR,LH)+2</p>	 <p><b>48530-06400-BFS</b> SHOCK ABS (RE,RH)</p>
 <p><b>48540-06400-BFS</b> SHOCK ABS (RE,LH)</p>	 <p><b>48510-80381-BFS</b> SHOCK ABS (FR,RH)+1</p>	 <p><b>48520-80140-BFS</b> SHOCK ABS (FR,LH)+2</p>
 <p><b>48530-80440-BFS</b> SHOCK ABS (RE RH/LH)</p>	 <p><b>56210-ED50D-BFS</b> SHOCK ABS (RE)</p>	 <p><b>56100-EB31B-BFS</b> SHOCK ABS</p>
 <p><b>MR554292-BFS</b> SHOCK ABS (FR)+2</p>	 <p><b>MR594956-BFS</b> SHOCK ABS (RE)+1</p>	 <p><b>48510-0K020-BFS</b> SHOCK ABS VIGO 2WD FR,RH+1</p>



## SHOCK ABSORBER

## BEFIRST

 <p><b>48520-0K020-BFS</b> SHOCK ABS VIGO 2WD FR,LH+2</p>	 <p><b>MR519614-BFS</b> SHOCK ABS (FR)</p>	 <p><b>MR519613-BFS</b> SHOCK ABS (RE)</p>
 <p><b>48531-0K010-BFS</b> SHOCK ABS (RE)</p>	 <p><b>56210-4M425-BFS</b> SHOCK ABS (RE)</p>	

